

COMBIVERT



Installation Manual

Housing B

1.5...2.2 kW

230 V

2.2...4.0 kW

400 V



The general EMC and safety directions at www.keb.de have to be observed!

| | |
|-------------|------|
| Mat.No. | Rev. |
| 00B60EMKB00 | 1G |





GB

This manual describes the KEB COMBIVERT B6. Particular attention is paid to the installation, the connection as well as the basic operation. Due to the various application and programming possibilities, the application-specific connection and/or wiring diagram, the parameter adjustment as well as instructions to the start-up are to be taken from the documentation of the machine manufacturer.

A list of instruction manuals and documents giving assistance for the construction, documentation and service is provided at the end of this manual. The safety and warning notes listed in this instruction manual as well as in other documentation must be observed at any rate to ensure a safe operation. The safety and warning instructions specified in this manual do not lay claim on completeness. KEB reserves the right to change/adapt specifications and technical data without prior notice. The used pictograms have following significance:



Danger
Warning
Caution



Attention
observe at
all costs



Information
Aide
Tip

The information contained in the technical documentation, as well as any user-specific advice in spoken and written and through tests, are made to best of our knowledge and information about the application. However, they are considered for information only without responsibility. This also applies to any violation of industrial property rights of a third-party.

Inspection of our units in view of their suitability for the intended use must be done generally by the user. Inspections are particularly necessary, if changes are executed, which serve for the further development or adaption of our products to the applications (hardware, software or download lists). Inspections must be repeated completely, even if only parts of hardware, software or download lists are modified. Original spare parts and authorized accessories by the manufacturer serve as security. The use of other parts excludes liability for the damages which can result from it.

Application and use of our units in the target products is outside of our control and therefore lies exclusively in the area of responsibility of the user.

Unauthorised opening and tampering may lead to bodily injury and property damage and may entail the loss of warranty rights.

| | | | |
|--|-----------|--|-----------|
| 1. Safety and Operating Instructions | 6 | 6. Error and Status Display..... | 28 |
| 2. Product description..... | 7 | Annex A | 35 |
| 2.1 Intended use..... | 7 | A.1 Overload characteristic..... | 35 |
| 2.2 Unit identification | 7 | A.2 Calculation of the motor voltage .. | 35 |
| 2.3 Technical data..... | 8 | A.3 Maintenance | 35 |
| 2.3.1 230 V class..... | 8 | A.4 Storage | 36 |
| 2.3.2 400 V class | 9 | A.5 Activation of the temperature input (only housing B)..... | 37 |
| 2.4 Dimensions and Terminals | 10 | Annex B | 39 |
| 3. Installation and Connection | 11 | B.1 CE-Marking..... | 39 |
| 3.1 Control cabinet installation | 11 | B.2 UL marking | 39 |
| 3.2 EMC conform Installation | 11 | B.3 Additional Manuals | 40 |
| 3.3 Connection of power circuit | 12 | | |
| 3.3.1 Wiring instructions..... | 12 | | |
| 3.3.2 Mains connection | 12 | | |
| 3.3.3 DC connection..... | 13 | | |
| 3.3.4 Motor connection..... | 13 | | |
| 3.3.5 Wiring example braking resistor | 14 | | |
| 3.3.6 Note to the function | 14 | | |
| 3.4 Control board xxB6Axx-xxx (default) | 15 | | |
| 3.4.1 X2A Control terminal strip..... | 15 | | |
| 3.4.2 Connection of the control terminal strip..... | 16 | | |
| 3.5 Control board xxB6Bxx-xxx (CAN)..... | 17 | | |
| 3.5.1 X2A Control terminal strip..... | 17 | | |
| 3.5.2 Connection of the control terminal strip..... | 18 | | |
| 4 Operation of the Unit..... | 19 | | |
| 4.1 Overview of the operating elements | 19 | | |
| 4.2 Keyboard operation | 19 | | |
| 4.2.1 Parameter numbers and values | 19 | | |
| 4.2.2 Resetting error messages | 19 | | |
| 4.2.3 Password input CP.0 | 20 | | |
| 4.2.4 Drive mode | 21 | | |
| 5. Parameter Description | 22 | | |

1. Safety and Operating Instructions



Safety and Operating Instructions for drive converters

(in conformity with the Low-Voltage Directive 2006/95/EC)

1. General

In operation, drive converters, depending on their degree of protection, may have live, uninsulated, and possibly also moving or rotating parts, as well as hot surfaces.

In case of inadmissible removal of the required covers, of improper use, wrong installation or maloperation, there is the danger of serious personal injury and damage to property.

For further information, see documentation.

All operations serving transport, installation and commissioning as well as maintenance are to be carried out by skilled technical personnel (Observe IEC 364 or CENELEC HD 384 or DIN VDE 0100 and IEC 664 or DIN/VDE 0110 and national accident prevention rules!).

For the purposes of these basic safety instructions, „skilled technical personnel“ means persons who are familiar with the installation, mounting, commissioning and operation of the product and have the qualifications needed for the performance of their functions.

2. Intended use

Drive converters are components designed for inclusion in electrical installations or machinery.

In case of installation in machinery, commissioning of the drive converter (i.e. the starting of normal operation) is prohibited until the machinery has been proved to conform to the provisions of the directive 2006/42/EC (Machinery Safety Directive - MSD). Account is to be taken of EN 60204.

Commissioning (i.e. the starting of normal operation) is admissible only where conformity with the EMC directive (2004/108/EC) has been established.

The drive converters meet the requirements of the Low-Voltage directive 2006/95/EC. They are subject to the harmonized standards of the series DIN EN 50178/VDE 0160 in conjunction with EN 60439-1/ VDE 0660, part 500, and EN 60146/ VDE 0558.

The technical data as well as information concerning the supply conditions shall be taken from the rating plate and from the documentation and shall be strictly observed.

3. Transport, storage

The instructions for transport, storage and proper use shall be complied with.

The climatic conditions shall be in conformity with EN 50178.

4 Installation

The installation and cooling of the appliances shall be in accordance with the specifications in the pertinent documentation.

The drive converters shall be protected against excessive strains. In particular, no components must be bent or isolating distances altered in the course of transportation or handling. No contact shall be made with electronic components and contacts.

Drive converters contain electrostatic sensitive components which are liable to damage through improper use. Electric components must not be mechanically damaged or destroyed (potential health risks).

5. Electrical connection

When working on live drive converters, the applicable national accident prevention rules (e.g. VBG 4) must be complied with.

The electrical installation shall be carried out in accordance with the relevant requirements (e.g. cross-sectional areas of conductors, fusing, PE connection). For further information, see documentation.

Instructions for the installation in accordance with EMC requirements, like screening, earthing, location of filters and wiring, are contained in the drive converter documentation. They must always be complied with, also for drive converters bearing a CE marking. Observance of the limit values required by EMC law is the responsibility of the manufacturer of the installation or machine.

6. Operation

Installations which include drive converters shall be equipped with additional control and protective devices in accordance with the relevant applicable safety requirements, e.g. act respecting technical equipment, accident prevention rules etc.. Changes to the drive converters by means of the operating software are admissible.

After disconnection of the drive converter from the voltage supply, live appliance parts and power terminals must not be touched immediately because of possibly energized capacitors. In this respect, the corresponding signs and markings on the drive converter must be respected.

During operation, all covers and doors shall be kept closed.

7. Maintenance and servicing

The manufacturer's documentation shall be followed.

KEEP SAFETY INSTRUCTIONS IN A SAFE PLACE!

2. Product description

2.1 Intended use

The frequency inverter KEB COMBIVERT B6 serves exclusively for the control and regulation of asynchronous motors. The operation of other electric consumers is prohibited and can lead to the destruction of the unit.

Frequency inverter are components which are intended for the installation in electric systems or machines.

2.2 Unit identification

| | | | | | | | | | |
|--|----|----------------------|---|---|-------------------------|---|---|---|--|
| 12 | B6 | A | 3 | B | 3 | 9 | 0 | 0 | |
| Cooling | | | | | | | | | |
| 0: Heat sink | | | | | 1: Flat rear | | | | |
| reserved | | | | | | | | | |
| Switching frequency; short time current limit; overcurrent limit | | | | | | | | | |
| 8: 2 kHz; 180 %; 216 % | | | | | A: 8 kHz; 180 %; 216 % | | | | |
| 9: 4 kHz; 180 %; 216 % | | | | | B: 16 kHz; 180 %; 216 % | | | | |
| Input identification | | | | | | | | | |
| 0: | | 1-phase 230V AC/DC | | | 6: 1-phase 230V AC | | | | |
| 1: | | 3-phase 230V AC/DC | | | 8: 1/3-phase 230V AC | | | | |
| 2: | | 1/3-phase 230V AC/DC | | | 9: 3-phase 400V AC | | | | |
| 3: | | 3-phase 400V AC/DC | | | A: 1-phase 110V AC | | | | |
| Housing type B | | | | | | | | | |
| Accessories | | | | | | | | | |
| 0: none | | | | | | | | | |
| 1: Braking transistor (GTR7) | | | | | | | | | |
| 2: internal filter | | | | | | | | | |
| 3: Braking transistor (GTR7) and internal filter | | | | | | | | | |
| Control type | | | | | | | | | |
| A: Standard (PNP) | | | | | C: Standard (NPN) *) | | | | |
| B: CAN (PNP) | | | | | D: CAN (NPN) *) | | | | |
| *) on request | | | | | | | | | |
| Series B6 | | | | | | | | | |
| Inverter size | | | | | | | | | |

Product description

2.3 Technical data

2.3.1 230 V class

| Inverter size | | 09 | | 10 | |
|---|--------------------|--|----------|-----------|----------|
| Housing size | | B | | | |
| Phases | | 1 | 3 | 1 | 3 |
| Output rated power | [kVA] | 2.8 | | 4.0 | |
| Max. rated motor power | [kW] | 1.5 | | 2.2 | |
| Output rated current | [A] | 7.0 | | 10 | |
| Max. short time current | [A] | 12.6 | | 18 | |
| OC-tripping current | [A] | 15.1 | | 21 | |
| Input rated current | [A] | 14 | 9.8 | 20 | 14 |
| Max. permissible mains fuse (inert) | [A] | 20 | 16 | 25 | 20 |
| Rated switching frequency | [kHz] | 4 | | 4 | |
| Max. switching frequency | [kHz] | 16 | | 16 | |
| Power loss at nominal operating | [W] | | | | |
| Input rated voltage | [VAC] | 230 (UL:200...240) | | | |
| Input voltage range U_{mains} | [VAC] | 180...264 \pm 0 | | | |
| Mains forms | | TN, TT, IT ²⁾ , Delta ³⁾ | | | |
| Mains frequency | [Hz] | 50...60 \pm 2 | | | |
| Output voltage | [V] | 3 x 0... U_{mains} | | | |
| Output frequency | [Hz] | 0...400 | | | |
| Min. motor line cross section | [mm ²] | 1.5 | | 2.5 | |
| Max. motor line length (shielded) | [m] | 30 at limit value class C2 10 at limit value class C1 | | | |
| For use in USA | | | | | |
| Max. mains fuse type RK5 | [A] | 20 | 15 | 30 | 25 |
| Max. input fusing MMC type "E" | 4) [A] | 16 | 20 | 25 | 20 |
| With integrated braking transistor | | | | | |
| Typically braking resistor | [Ω] | 100 | | 68 | |
| Maximal braking current | [A] | 9.5 | | 12 | |
| Leakage current with internal filter (at nOP) | [mA] | 6 | | | |

2)insulating resistance at mains form IT = 2M Ω

3)on inquiry

4)see 400 V class



Site altitude maximal 2000 m above sea level. With site altitudes over 1000 m a derating of 1 % per 100 m must be taken into consideration.

2.3.2 400V class

| | | | |
|---|--------------------|--|-----------|
| Inverter size | | 10 | 12 |
| Housing size | | B | |
| Phases | | 3 | |
| Output rated power | [kVA] | 4 | 6.6 |
| Max. rated motor power | [kW] | 2.2 | 4 |
| Output rated current | [A] | 5.8 | 9.5 |
| Max. short time current | [A] | 10.4 | 17 |
| OC-tripping current | [A] | 12.5 | 21 |
| Input rated current | [A] | 8 | 13 |
| Max. permissible mains fuse (inert) | [A] | 16 | 20 |
| Rated switching frequency | [kHz] | 4 | 4 |
| Max. switching frequency | [kHz] | 8 | 8 |
| Power loss at nominal operating | [W] | | |
| Input rated voltage | 1) [V] | 400 (UL:400...480) | |
| Input voltage range U_{mains} | [V] | 305...528 \pm 0 | |
| Mains forms | | TN, TT, IT ²⁾ , Delta ³⁾ | |
| Mains frequency | [Hz] | 50...60 \pm 2 | |
| Output voltage | [V] | 3 x 0... U_{mains} | |
| Output frequency | [Hz] | 0...400 | |
| Min. motor line cross section | [mm ²] | 1.5 | 2.5 |
| Max. motor line length (shielded) | [m] | 30 at limit value class C2 | |
| For use in USA | | | |
| Max. mains fuse type RK5 | [A] | 12 | 15 |
| Max. input fusing MMC type "E" | 4) [A] | 12 | 16 |
| With intergrated braking transistor | | | |
| Typically braking resistor | [Ω] | 270 | 150 |
| Maximal braking current | [A] | 10 | 10 |
| Leakage current with internal filter (at nOP) | [mA] | 6 | |

1) at mains voltage ≥ 460 V multiply the nominal current with factor 0.86.

2) insulating resistance at mains form IT = 2 M Ω

3) on inquiry

4) use E-MMC/ Type E - Manual Motor Controller according to UL508 / Class NKJH only. The following types are accepted:


| Manufacturer | UL - File | Type | Required terminal line adaptor |
|--------------------------|-----------|-------------------------------|--------------------------------|
| Siemens | E 156943 | 3RV1021-1xA10 | 3RV1928-1H |
| | | 3RV1031-4xA10 | - |
| ABB Stotz | E 195536 | MS325-xx | S3-M3 |
| | | MS450-xx | - |
| Rockwell / Allen Bradley | E 205542 | 140M-C2E-Bxx or Cxx | - |
| | | 140M-F8E-Cxx | - |
| Moeller | E 123500 | PKZM0-xxE (only up to 25A) | BK25/3 - PKZ0-E |

Where x or xx means that here current rating or letter for current rating is given.

Use only in mains Wye 480/277 V. Delta grounding is not permitted.

Product description

2.4 Dimensions and Terminals



X1A Connection for mains supply

X1B Connection for motor, braking resistor and temperature detection

X2A Connection for control lines

X6B HSP5 Interface for parametrizing. Used accessories for PC connection:

- Adapter SUB-D9 to RJ45 (mat.no. 00F50C0-0020)
- RS232/HSP5 converter (mat.no. 00F50C0-0010)



Connection protective conductor

3. Installation and Connection

3.1 Control cabinet installation


| | |
|---------------------------------|----------------------------|
| Protective system (EN 60529) | IP20 |
| Operation temperature | -10...40 °C (14...104 °F) |
| Storage temperature | -25...70 °C (-13...158 °F) |
| Max. heat sink temperature | 90 °C (194 °F) |
| Climatic category (EN60721-3-3) | 3K3 |
| Environment (IEC 664-1) | Pollution degree 2 |
| Vibration/Jolt according to | German. Lloyd; EN50155 |

The flat-rear design (projected) requires cooling measures by the machine builder. This can be in the best case no further measure at all (e.g. at cyclic operation with down times) up to the dissipation of the entire, indicated heat loss at rated operation.



The COMBIVERT must be protected against aggressive gases, aerosols and conductive dust!


Installation position and min. distances



3.2 EMC conform Installation

- Always apply the shielding of motor and control cables over a large contact surface on both sides.
- Distance between control and power cables at least 10...20 cm (4...8 inch).
- Lay motor and power cable separately.
- If it cannot be avoided, cross control and power cables in a right angle.
- Install all cables as close as possible to the mounting plate - ideal in a metal cable duct.
- Mount COMBIVERT well conducting with the mounting plate. Remove the paint beforehand.

You can find further instructions regarding the EMC-conform wiring in the Internet at KEB.



Installation and Connection

3.3 Connection of power circuit

3.3.1 Wiring instructions



Absolutely observe the connecting voltage of the KEB COMBIVERT. A 230V-unit will be immediately destroyed on a 400V-power supply.



Never exchange the mains and motor cables.



Some countries demand that the PE-terminal is directly connected to the terminal box (not over the mounting plate).

3.3.2 Mains connection

| | |
|--|--|
| <p>Mains connection 230V class 1-phase</p> <p>Terminal strip X1A Input voltage 1 AC 180...264±0V</p> | <p>Mains connection 400V class 3-phase</p> <p>Terminal strip X1A Input voltage 1 AC 305...528±0V</p> |
| <p>Mains connection 230V class 3-phase</p> <p>Terminal strip X1A Input voltage 3 AC 180...264±0V</p> | |
| <p>Protection (see „Technical data“) or power protective switch 1-phase inverter RCD type A or type B 3-phase inverter RCMA with separator or RCD type B</p> | |
| <p>Connection cross-section 1.5...4 mm² (AWG 16-11) Tightening torque 0.6 Nm (5 lb inch)</p> | |

3.3.3 DC connection

| | |
|--|---|
| DC connection | |
| Input voltage 230 V-class: 250...370 VDC | |
| Input voltage 400 V-class: 420...720 VDC | |
| | |
| Terminal strip X1B | |
| Tightening torque 0.6 Nm (5 lb inch) | |
| Connection cross-section 1.5...4 mm ² (AWG 16-11) | |
| | At DC supply pay attention to the permissible voltage range of the fuses! |

3.3.4 Motor connection

| | |
|---|--|
| | Max. motor line length see „Technical data“ |
| | |
| Apply shieldings over a large contact surface of the mounting plate! | Terminal strip X1B |
| | Tightening torque 0.6 Nm (5 lb inch) |
| | Connection cross-section 1.5...4 mm ² (AWG 16-11) |
| 1) Motor temperature monitoring T1, T2 (the evaluation can be activated by CP.36) | |
| • Tripping resistance 1.65...4 kΩ | |
| • Reset resistance 0.75...1.65 kΩ | |
| • Design in accordance with VDE 0660 Part 302 | |
| • Do not lay connecting cable together with control cable. | |
| • Permissible in the motor cable only with double shielding. | |


3.4 Control board xxB6Axx-xxx (default)

3.4.1 X2A Control terminal strip



The control connections are „safety separated circuits“ according to PELV requirements.

- Conductor cross-section AWG 20-16 rigidly or flexibly 0.5...1.5 mm²
- Wire-end ferrule without plastic case 0.5...1 mm²
- Wire-end ferrule with plastic case 0.5 mm²
- Strip length 8 mm
- Use shielded / drilled cables
- Lay shield on one side of the inverter onto earth potential



| PIN | Function | Name | Description |
|--|----------------------------|------|---|
| Analog input and output | | | |
| 1 | Analog output | AO1 | Output of the actual output frequency 0...100 Hz => 0...10 VDC (max. 10 mA) R _i = 100 Ω; Resolution 11 Bit |
| 2 | Function | AN1+ | Setpoint input resolution 10 Bit (reversible with CP.35) 0...10 VDC; R _i = 29 kΩ (factory setting) 0...20 mA, 4...20 mA; R _i = 500 Ω |
| Voltage supply | | | |
| 3 | Mass | COM | Mass for analog and digital inputs/outputs |
| 4 | +15V Output | +15V | Stabilized supply voltage for digital inputs and setpoint poti +15 VDC ±8 % / max. 50 mA Observe input voltage of analog input! |
| Programmable digital inputs 13...30 VDC ±0 % smoothed; R_i: 2.2 kΩ; scan time: ≤10 ms | | | |
| 5 | Control release / Reset | ST | Power modules are enabled; reset at opening |
| 6 | Forward | F | Rotation selection |
| 7 | Reverse | R | Forward has priority |
| 8 | Fixed frequency 1 (CP.19) | I1*) | I1 + I2 = fixed frequency 3 (CP.21) |
| 9 | Fixed frequency 2 (CP.20) | I2 | |
| Programmable digital output 15 VDC ±10 % max. 50 mA | | | |
| 10 | Digital output | O1 | Frequency dep. switch (factory setting) Output switches at actual frequency = setpoint frequency Programmable with CP.32 |
| Programmable relay output max. 30 VDC / 0.01...1 A | | | |
| 11 | Relay 1 / NO contact | RLA | Fault signalling relay (factory setting) Programmable with CP.33 |
| 12 | Relay1 / NC contact | RLB | |
| 13 | Relay1 / switching contact | RLC | |

*) I1 can be changed in the application mode to a scan time of 2 ms.

3.5 Control board xxB6Bxx-xxx (CAN)

3.5.1 X2A Control terminal strip




The control connections are „safety separated circuits“ according to PELV requirements.

| | | |
|--|---|------------|
| <ul style="list-style-type: none"> • Conductor cross-section AWG 20-16 rigidly or flexibly • Wire-end ferrule without plastic case • Wire-end ferrule with plastic case • Strip length • Use shielded / drilled cables • Lay shield on one side of the inverter onto earth potential | <p>0.5...1.5 mm²</p> <p>0.5...1 mm²</p> <p>0.5 mm²</p> <p>8 mm</p> | <p>X2A</p> |
|--|---|------------|

| PIN | Function | Name | Description |
|--|----------------------------|-------|--|
| CAN interfaces | | | |
| 1 | CAN high | CAN-H | Input and output of the CAN bus are parallel connected to the corresponding terminals high and low. |
| 2 | CAN low | CAN-L | |
| Voltage supply | | | |
| 3 | Mass | COM | Mass for digital inputs/outputs |
| 4 | +15V Output | +15V | Stabilized supply voltage for digital inputs and setpoint poti +15VDC ±8% / max. 50mA |
| Programmable digital inputs 13...30VDC ±0% smoothed; Ri: 2.2kΩ; scan time: ≤10ms | | | |
| 5 | Control release / Reset | ST | Power modules are enabled; reset at opening |
| CAN interfaces | | | |
| 6 | CAN shielding | CAN | Connection for shielding of the bus cables. |
| 7 | -reserved- | - | |
| 8 | -reserved- | - | |
| 9 | -reserved- | - | |
| Programmable digital output 15VDC ±10% max. 50mA | | | |
| 10 | Digital output | O1 | Frequency dep. switch (factory setting) Output switches at actual frequency = setpoint frequency Programmable with CP.32 |
| Programmable relay output max. 30VDC / 0.01...1A | | | |
| 11 | Relay 1 / NO contact | RLA | Fault signalling relay (factory setting) Programmable with CP.33 |
| 12 | Relay1 / NC contact | RLB | |
| 13 | Relay1 / switching contact | RLC | |


Installation and Connection

3.5.2 Connection of the control terminal strip



4 Operation of the Unit

4.1 Overview of the operating elements



4.2 Keyboard operation

4.2.1 Parameter numbers and values

When switching on KEB COMBIVERT B6 the value of parameter CP.1 appears.

The function key changes between the parameter value and parameter number.



With UP (▲) and DOWN (▼) the parameter number or at changeable parameters the value is increased/ decreased.



Principally during a change, parameter values are immediately accepted and stored non-volatile. However, with some parameters it is not useful that the adjusted value is accepted immediately. In these cases the adjusted value is accepted and stored non-volatile by pressing ENTER. When this type of parameter is changed a point appears behind the last digit.

By pressing „ENTER“ the adjusted value is accepted and non-volatile stored.



4.2.2 Resetting error messages

If a malfunction occurs during operation, the actual display is overwritten by the error message. The error message in the display is reset by ENTER.



With ENTER only the error message in the display is reset. In order to reset the error, the cause must be removed and a reset or a power-on reset must be made.

Operation of the Unit

4.2.3 Password input CP.0

The KEB COMBIVERT is outfitted with an extensive password protection. Dependent on the entered password the following modes are possible:


| Display | Mode | Password ¹⁾ |
|-----------|---|------------------------|
| CP_ro | End customer menu (CP-Parameter) read-only | 100 |
| CP_on | End customer menu (CP-Parameter) read/write | 200 |
| CP_SE | Service menu (like end customer menu, but with the original parameters) | 330 |
| APPL | Application menu (all parameter groups and parameters are visible) | ²⁾ |
| see 4.2.4 | Drive mode (COMBIVERT can be put into operation by the keyboard) | 500 |

1) *The passwords must be made unrecognizable for protection against unauthorized access.*

2) *The password for the application menu is described in the application manual.*


The menu admissible for the application is defined by the machine builder. The password input is generally made over the parameter CP.0. The adjusted password/menu is maintained even after switching off.

Example: Changing the CP-parameter from read-only to read/write



4.2.4 Drive mode

The Drive Mode is an operating mode of KEB COMBIVERT that permits the manual starting of the drive by the keyboard. After switching the control release the set value and rotation setting are effected exclusively over the keyboard. In order to activate the drive mode the corresponding **password** (see 4.2.3) must be entered in **CP. 0**. The display switches over as follows:



To exit the drive mode the inverter must be in status "stop" (Display noP or LS). Press the FUNC and ENTER keys simultaneously for about 3 seconds to leave the drive mode. The CP-parameters appear in the display.



+



for 3 seconds

5. Parameter Description

| CP-Parameter ¹⁾ | Setting Range | Resolution | Default | Unit | ²⁾ | ³⁾ Based on |
|----------------------------|----------------------------------|------------------|---------|---------|---------------|---------------------------|
| CP.00 | Password input | 0...9999 | 1 | - | - | ud.01 |
| CP.01 | Actual frequency display | -400...400 | 0.0125 | 0 | Hz | ru.03 |
| CP.02 | Set frequency display | -400...400 | 0.0125 | 0 | Hz | ru.01 |
| CP.03 | Inverter status | 0...255 | 1 | 0 | - | ru.00 |
| CP.04 | Apparent current | 0...6553.5 | 0.1 | 0 | A | ru.15 |
| CP.05 | Apparent current / peak value | 0...6553.5 | 0.1 | 0 | A | ru.16 |
| CP.06 | Utilization | 0...65535 | 1 | 0 | % | ru.13 |
| CP.07 | DC link voltage | 0...1000 | 1 | 0 | V | ru.18 |
| CP.08 | DC link voltage / peak value | 0...1000 | 1 | 0 | V | ru.19 |
| CP.09 | Output voltage | 0...778 | 1 | 0 | V | ru.20 |
| CP.10 | Minimal frequency | 0...400 | 0.0125 | 0 | Hz | op.06 |
| CP.11 | Maximum frequency | 0...400 | 0.0125 | 70 | Hz | op.10 |
| CP.12 | Acceleration time | 0.00...300.00 | 0.01 | 5 | s | op.28 |
| CP.13 | Deceleration time (-0.01=CP.12) | -0.01...300.00 | 0.01 | 5 | s | op.30 |
| CP.14 | S-curve time | off; 0.01...5.00 | 0.01 | off | s | op.32 |
| CP.15 | Boost | 0.0...25.5 | 0.1 | LTK | % | uf.01 |
| CP.16 | Rated frequency | 0...400 | 0.0125 | 50 | Hz | uf.00 |
| CP.17 | Voltage stabilization | 0...649, off | 1 | off | V | E uf.09 |
| CP.18 | Switching frequency | 0...LTK | 1 | LTK | - | E uf.11 |
| CP.19 | Fixed frequency 1 | -400...400 | 0.0125 | 5 | Hz | op.21 |
| CP.20 | Fixed frequency 2 | -400...400 | 0.0125 | 50 | Hz | op.22 |
| CP.21 | Fixed frequency 3 | -400...400 | 0.0125 | 70 | Hz | op.23 |
| CP.22 | DC braking / mode | 0...9 | 1 | 7 | - | E pn.28 |
| CP.23 | DC braking / time | 0.00...100.00 | 0.01 | 10 | s | pn.30 |
| CP.24 | Max. ramp current | 0...200 | 1 | 140 | % | pn.24 |
| CP.25 | Max. constant current | 0...200 | 1 | 200:off | % | pn.20 |
| CP.26 | Speed search / condition | 0...15 | 1 | 8 | - | E pn.26 |
| CP.27 | Motor protection / response | 0...6 | 1 | 6 | - | pn.14 |
| CP.28 | Motor protection / mode | 0...1 | 1 | 1 | - | dr.11 |
| CP.29 | Motor protection / rated current | 0.0...370.0 | 0.1 | LTK | A | dr.12 |
| CP.30 | Analog output / function | 0...26 | 1 | 2 | - | E an.31 |
| CP.31 | Analog output / amplification | -20.00...20.00 | 0.01 | 1 | - | an.33 |
| CP.32 | Transistor output / function | 0...80 | 1 | 20 | - | E do.00 |
| CP.33 | Relay output / function | 0...80 | 1 | 4 | - | E do.02 |
| CP.34 | Relay output / switching level | ±30000.00 | 0.01 | 100.00 | - | le.02 |
| CP.35 | Set value selection | 0...2 | 1 | 0 | - | E an.00 |
| CP.36 | Select 50/60Hz mode | 0...1 | 1 | 0 | - | E ud.06 |

1) The CP-Parameter group is a selection of more than 500 parameters and 8 parameter sets for simple applications. Each CP-Parameter (not CP.00) can be individually assigned so a special final customer menu is generated. Further documentation is specified at the end of this manual.

2) ENTER parameter see 4.2.1

3) The origin parameters are indicated in the service menu (CP_SE) and in the application menu.

CP.03 Inverter status

The actual operating condition of the frequency inverter is displayed in parameter „inverter status“. In the case of an error the current error message is displayed, even if the display has already been reset with ENTER (error-LED on the operator is still blinking).

| | |
|------|--|
| nOP | „no Operation“; control release not bridged; modulation switched off; output voltage = 0V; drive is not controlled. |
| LS | „Low Speed“; no direction of rotation preset; modulation switched off; output voltage = 0V; drive is not controlled. |
| FAcc | „Forward Acceleration“; drive accelerates with direction of rotation forward. |
| FdEc | „Forward Deceleration“; drive decelerates with direction of rotation forward. |
| rAcc | „Reverse Acceleration“; drive accelerates with direction of rotation reverse. |
| rdEc | „Reverse Deceleration“; drive decelerates with direction of rotation reverse. |
| Fcon | „Forward Constant“; drive runs with constant speed and direction of rotation forward. |
| rcon | „Reverse Constant“; drive runs with constant speed and direction of rotation reverse. |

Status messages and information about the cause and removal are to be found in www.keb.de > *Service&Downloads* > *Downloads* ==> *status_gb.pdf*.

CP.17 Voltage stabilization

With this parameter a regulated output voltage in relation to the rated frequency can be adjusted. For that reason voltage variations at the input as well as in the intermediate circuit only have a small influence on the output voltage (U/f-characteristic). The function allows, among other things, an adaption of the output voltage to special motors.

CP.22 DC braking / mode

With DC braking the motor is not decelerated by the ramp. Quick braking is caused by DC voltage, which is applied onto the motor winding. This parameter determines how the DC braking is triggered.

| Value | Activation |
|-------|---|
| 0 | DC braking deactivated |
| 1 | DC braking at switch off of the direction of rotation and upon reaching 0Hz. The braking time is CP.23 or until the next direction of rotation. |
| 2* | DC braking as soon as setting for the direction of rotation is absent. |
| 3* | DC braking as soon as the direction of rotation changes or is absent. |
| 4* | DC braking at switch off of the direction of rotation and upon reaching 4 Hz. |
| 5* | DC braking when the real frequency falls below 4 Hz and the drives decelerates |
| 6* | DC braking as soon as the set value falls below 4 Hz. |
| 7 | reserved |
| 8 | reserved |
| 9 | DC braking after switching on the modulation. |

* Braking time depends on the actual frequency.

CP.24 Max. ramp current

This function protects the frequency inverter against switching off through overcurrent during the acceleration ramp. When the ramp reaches the adjusted value, it is stopped so long until the current decreases again. CP.03 displays "LAS" at active function.

CP.25 Max. constant current

This function protects the frequency inverter against switch off through overcurrent during constant output frequency. When exceeding the adjusted value, the output frequency is reduced until the value drops below the adjusted value. CP. 03 displays "SSL" at active function.

CP.26 Speed search / condition

When connecting the frequency inverter onto a decelerating motor, an error can be triggered by the differing rotating field frequencies. With activated speed search the inverter searches for the actual motor speed, adapts its output frequency and accelerates with the adjusted ramp to the given set value. During speed search CP.03 displays "SSF". The parameter determines on what conditions the function operates.

In case of several conditions the sum of the value must be entered. Example: CP.26 = 12 means after reset **and** after auto-reset UP.

| Value | Condition |
|-------|---------------------|
| 0 | Function off |
| 1 | at control release |
| 2 | at switch on |
| 4 | after reset |
| 8 | after auto-reset UP |

CP.27 Motor protection / response

The motor protective function protects the connected motor against thermal destruction caused by high currents. The function corresponds largely to mechanical motor protective components, additionally the influence of the motor speed on the cooling of the motor is taken into consideration. The load of the motor is calculated from the measured apparent current (CP.04) and the adjusted rated motor current (CP.29).

For motors with separately driven fan or rated frequency of a self-ventilated motor following tripping times (VDE 0660, part 104) apply:

| | | | | |
|-----|---|---------------|---|-----------|
| 1.2 | • | Rated current | ≤ | 2 hours |
| 1.5 | • | Rated current | ≤ | 2 minutes |
| 2 | • | Rated current | ≤ | 1 minute |
| 8 | • | Rated current | ≤ | 5 seconds |

In case of failure CP.27 activates the motor protection function and adjusts the corresponding response as follows:

| CP.27 | Response | Description |
|----------------------|---|---|
| 0 | Error, restart after reset Error message E.xx | Immediate switch off of the modulation. Correct the error for the restart and activate reset. The prewarning changes into an error. The drive remains in the error state until a reset signal is recognized. |
| further on next side | | |

| CP.27 | Response | Description |
|-------|--|--|
| 1 | Quick stopping, modulation off, restart after reset Status message A.xx | Fast stop - switch off of the modulation after reaching 0 Hz. Correct the error for the restart and activate reset. The drive remains in condition fast stop until a reset signal is recognized. |
| 2 | Quick stopping, holding torque, restart after reset Status message A.xx | Fast stop - holding torque on reaching 0 Hz. Correct the error for the restart and activate reset. The drive remains in condition fast stop until a reset signal is recognized. |
| 3 | modulation off, automatic restart Status message A.xx | Immediate switch off of the modulation; the drive returns automatically to normal operation, as soon as the fault no longer exists. |
| 4 | Quick stopping, modulation off, automatic restart Status message A.xx | Fast stop - switch off of the modulation after reaching 0 Hz. the drive returns automatically to normal operation, as soon as the fault no longer exists. |
| 5 | Quick stopping, holding torque, automatic restart Status message A.xx | Fast stop - holding torque on reaching 0 Hz. the drive returns automatically to normal operation, as soon as the fault no longer exists. |
| 6 | Warning signal by digital output, no message | No effect to the drive. Error is being ignored. Switching conditions (CP.32 and CP.33) value „10“ are set. |

CP.28 Motor protection / mode

The cooling mode of the motor is adjusted with these programmable parameters.

| Value | Condition |
|-------|-----------------------------|
| 0 | Motor with separate cooling |
| 1 | Motor with self-cooling |

For self-ventilated motors the tripping times decrease with the frequency of the motor. The motor protective function acts integrating, i.e. times with overload on the motor are added, times with underload are subtracted. After triggering the motor protective function, the new tripping time is reduced to 1/4 of the specified value, if the motor has not been operated for an appropriate time with underload.

CP.29 Motor protection / rated current

This parameter specifies the rated current (= 100% utilization) for the motor protective function. The motor protection-load is calculated as follows:

$$\text{Motor protection load} = \frac{\text{Inverter apparent current (CP.04)}}{\text{Motor protection / rated current (CP.29)}}$$

CP.30 Analog output 1 / function

CP.30 defines the function of analog output 1. The output at the analog output is always made in a range of 0...+10 V. Negative values are inverted and the output is displayed in a positive value.

| Value | Function | Scaling factor 0...100% (0...±100%) |
|---------|---|--|
| 0 | Absolute actual frequency CP.1 | 0...100Hz |
| 1 | Absolute set frequency CP.2 | 0...100Hz |
| 2 | Actual frequency CP.1 | 0...±100Hz |
| 3 | Set frequency CP. 2 | 0...±100Hz |
| 4 | Output voltage CP.9 | 0...500V |
| 5 | DC link voltage CP.7 | 0...1000V |
| 6 | Apparent current CP.4 | 0...2 • rated current |
| 7 | Active current ru.17 | 0...2 • ±rated current |
| 8...10 | reserved | – |
| 11 | Absolute active current ru.17 | 0...2 • rated current |
| 12 | Power stage temperature ru.38 | 0...100 °C |
| 13...21 | reserved | – |
| 22 | Analog input before amplification (ru.27) | 0...100% |
| 23 | Analog input after amplification (ru.28) | 0...400% |
| 24...25 | reserved | – |
| 26 | Active power ru.81 | 0...±2 • Rated power |

CP.32 Transistor output / function (term. X2A.10)

The switching level of CP.32 is pre-set to 4,00. Value range see CP.33.

CP.33 Relay output 1 / function (terminals X2A.11...13)

The switching level of CP.33 is adjusted by CP.34.

| Value | Function |
|-------|--|
| 0 | No function (generally off) |
| 1 | Generally on |
| 2 | Run signal; also by DC-braking |
| 3 | Ready signal (no error) |
| 4 | Fault relay |
| 5 | Fault relay (without auto-reset) |
| 6 | Warning or error message at abnormal stopping |
| 7 | Overload pre-warning (OL) |
| 8 | Overtemperature pre-warning (OH) |
| 9 | External overtemperature |
| 10 | Motor protection pre-warning (OH2) |
| 11 | Interior temperature pre-warning (OHI) |
| 12 | Cable breakage 4...20 mA on analog input 1 |
| 14 | max. constant current (Stall, CP.25) exceeded |
| 15 | max. ramp current (LA-Stop, CP.24) exceeded |
| 16 | DC-braking active |
| 20 | Actual value = set value (CP.3 = Fcon; rcon; not at noP, LS, error, SSF) |
| 21 | Accelerate (CP.3=Facc, rAcc, LAS) |
| 22 | Decelerate (CP.3 = FdEc, rdEc, LdS) |

further on next side

| Value | Function |
|-------|--|
| 23 | Real direction of rotation = set direction of rotation |
| 24 | Utilization (CP.6) > switching level |
| 25 | Active current > switching level |
| 26 | Intermediate circuit voltage (CP.7) > switching level |
| 27 | Real value (CP.1) > switching level |
| 28 | Set value (CP.2) > switching level |
| 31 | Absolute set value at AN1 > switching level |
| 34 | Set value at AN1 > switching level |
| 40 | Hardware current limit activated |
| 41 | Modulation on |
| 44 | Inverter status > switching level |
| 47 | Ramp output value > switching level |
| 48 | Apparent current (CP.4) > switching level |
| 49 | Forward running (not at nOP, LS, abnormal stopping or error) |
| 50 | Reverse running (not at nOP, LS, abnormal stopping or error) |
| 63 | Absolut ANOUT1 > switching level |
| 65 | ANOUT1 > switching level |
| 73 | Absolute active power > switching level |
| 74 | Active power > switching level |
| 80 | Active current > switching level |
| 84 | Actual value < minimum setpoint |

No listed values are only for the application mode.

CP.35 AN1 Set value selection

The setpoint input (AN1) of the control can be triggered with different signal levels. In order to correctly evaluate the signal, this parameter must be adapted to the signal source.

| Value | Set value signal |
|-------|---------------------------------------|
| 0 | 0...10VDC / $R_i = 29\text{ k}\Omega$ |
| 1 | 0...20mADC / $R_i = 500\ \Omega$ |
| 2 | 4...20mADC / $R_i = 500\ \Omega$ |

CP.36 Select 50/60Hz mode

When units or machines are delivered in the area of application of UL an adaption of the factory setting to the valid operating data there can be done with this parameter.

| Value | Default value |
|-------|--|
| 0 | Current values and limits, motor data, frequencies and speed relate to a 50 Hz mains with 400 V rated voltage. |
| 1 | Current values and limits, motor data, frequencies and speed relate to a 60 Hz mains with 460 V rated voltage. |

Error and Status Display

6. Error and Status Display

At KEB COMBIVERT error messages are always represented with an "E." and the appropriate error in the display. Error messages cause the immediate deactivation of the modulation. Restart possible only after reset or autoreset.

Malfunction are represented with an „A.“ and the appropriate message. Reactions to malfunctions can vary. In the following the display and their cause are described. Status is displayed without any additions.

| Display | COMBIVIS display | dec | hex | Meaning |
|---------|----------------------------|-----|-----|---|
| bbL | base block | 76 | 4C | The power modules for motor-de-excitation are locked after opening the control release or after an error. |
| boFF | open brake | 86 | 56 | This message is depending on the adjustment of the brake control mode. It is displayed during open (release) the brake. |
| bon | close brake | 85 | 55 | This message is depending on the adjustment of the brake control mode. It is displayed during close (engage) the brake. |
| Cdd | calculate drive data | 82 | 52 | Measurement of the motor stator resistance. |
| Cddr | calculate drive data ready | 127 | 7F | Measurement of the motor stator resistance successful completed. |
| dcb | DC brake | 75 | 4B | Motor is decelerated by a DC-voltage at the output. |
| dLS | low speed / DC brake | 77 | 4D | Modulation is switched off after DC-braking. |
| FAcc | forward acceleration | 64 | 40 | Acceleration with the adjusted ramps in clockwise direction of rotation (forward). |
| Fcon | forward constant | 66 | 42 | Acceleration / deceleration phase is completed and it is driven with constant speed / frequency in clockwise direction of rotation (forward). |
| FdEc | forward deceleration | 65 | 41 | It is stopped with the adjusted ramp times in clockwise direction of rotation (forward). |
| HCL | hardware current limit | 80 | 50 | The message is output if the output current reaches the hardware current limit. |
| LAS | LA stop | 72 | 48 | This message is displayed if during acceleration the load is limited to the adjusted load level. |
| LdS | Ld stop | 73 | 49 | This message is displayed if during deceleration the load is limited to the adjusted load level or the DC-link current to the adjusted voltage level. |
| LS | low speed | 70 | 46 | No direction of rotation pre-set, modulation is off. |
| nO_PU | power unit not ready | 13 | 0D | This message is displayed if during deceleration the load is limited to the adjusted load level or the DC-link current to the adjusted voltage level. |
| noP | no operation | 0 | 0 | Control release (terminal ST) is not switched. |
| PLS | low speed / power off | 84 | 54 | No modulation after Power-Off. |
| POFF | power off function | 78 | 4E | Is displayed during power-off function. Depending on the programming of the function the inverter restarts automatically upon system recovery or after a reset. |

further on next side

| Display | COMBIVIS display | dec | hex | Meaning |
|---------|-----------------------------|-----|-----|--|
| rAcc | reverse acceleration | 67 | 43 | Acceleration with the adjusted ramps in counterclockwise direction of rotation (reverse). |
| rcon | reverse constant | 69 | 45 | Acceleration / deceleration phase is completed and it is driven with constant speed / frequency in counterclockwise direction of rotation (reverse). |
| rdEc | reverse deceleration | 68 | 44 | Stopping with the adjusted ramps in counterclockwise direction of rotation (reverse). |
| SLL | stall | 71 | 47 | This message is displayed if during constant operation the load is limited to the adjusted current limit. |
| SSF | speed search | 74 | 4A | Speed search function active, that means that the inverter attempts to synchronize onto a running down motor. |
| STOP | quick stop | 79 | 4F | The message is output if as response to a warning signal the quick-stop function becomes active. |
| E. EF | Error! external fault | 31 | 1F | An external signal has released an error at a programmable input. |
| E. Pu | Error! power unit | 12 | 0C | General power circuit fault (e. g. fan) |
| E.Acc | Error! maximum acceleration | 24 | 18 | Acceleration exceeds the limit defined by Pn.79. |
| E. br | Error! brake | 56 | 38 | This error can occur in the case of switched on brake control. |
| | | | | The absence of a motor phase was detected at brake release. |
| | | | | The load reaches the hardware current limitation at brake release. |
| | | | | The load is below the minimum load level at brake release. |
| E.buS | Error! Watchdog | 18 | 12 | Adjusted monitoring time (Watchdog) of communication between operator and PC / operator and inverter has been exceeded. Check wiring and bus master (PC or SPS). |
| E.Cdd | Error! calc. drive data | 60 | 3C | Error: During the automatic motor stator resistance measurement. |
| E.dOH | Error! Motor temperature | 9 | 9 | Error: Overtemperature of motor PTC. Error can only be reset at E.ndOH, if PTC is again low-resistance. |
| | | | | No motor overheat connected, but activated in the parameter. Install bridge between T1/t2. |
| | | | | resistance at the terminals T1/T2 >1650 Ohm |
| | | | | line breakage to the temperature sensor |
| | | | | Check motor cooling |
| | | | | motor overloaded |

further on next side

Error and Status Display

| Display | COMBIVIS display | dec | hex | Meaning |
|---------|---------------------------|-----|-----|--|
| E.dri | Error! driver relay | 51 | 33 | Error: Driver relay. Relay for driver voltage on power circuit has not picked up even though control release was given. |
| E.EEP | Error! EEPROM defective t | 21 | 15 | After reset the operation is again possible (without storage in the EEPROM) |
| E.iEd | Error! input error detect | 53 | 35 | Hardware failure at the NPN/PNP change-over or at the start/stop measurement. |
| E.InI | Error! initialisation MFC | 57 | 39 | MFC not booted. |
| E.LSF | Error! load shunt fault | 15 | 0F | Load-shunt relay has not picked up. occurs for a short time during the switch-on phase, but must automatically be reset immediately. High losses in the supply cable braking resistor wrongly connected or damaged Control of line contactor and input fuses. braking module defective load-shunt defective input voltage wrong or too low |
| E.ndOH | no ERROR drive overheat | 11 | 0B | Motor temperature switch or PTC at the terminals T1/T2 is again in the normal operating range. Message E.ndOH is displayed. The error can be reset now. |
| E.nOH | no E. over heat pow. mod. | 36 | 24 | Temperature of the heat sink is again in the permissible operating range. The error E.OH can be reset. |
| E.nOHI | no ERROR overheat int. | 7 | 7 | No longer overheating in the interior E.OHI, interior temperature has fallen by at least 3°C. |
| E.nOL | no ERROR overload | 17 | 11 | After the error E.OL a cooling phase must be elapsed. OL- counter has reached 0 %; message E.nOL is displayed and the error can be reset. |
| E.nOL2 | no ERROR overload 2 | 20 | 14 | The cooling time has elapsed. The error can be reset. |
| | | | | further on next side |

| Display | COMBIVIS display | dec | hex | Meaning |
|--|------------------------------|-----|-----|--|
| E. OC | Error! overcurrent | 4 | 4 | Occurs, if the specified peak current is exceeded. |
| | | | | Short circuit at the output |
| | | | | Ground fault |
| | | | | motor cable too long |
| | | | | Phase error |
| | | | | EMC |
| | | | | The load is too big at turned off constant current limit. |
| | | | | DC brake at high ratings active |
| | | | | Deceleration ramp or stopping jerk is adjusted too short. |
| | | | | Braking transistor defective or missing |
| E. OH | Error! heat sink temperature | 8 | 8 | Error: Overtemperature of power module. Error can only be reset at E.nOH. |
| | | | | Installation position and minimum distances wrong |
| | | | | ambient temperature too high |
| | | | | Fan clogged or defective |
| E.OH2 | Error! motor protection | 30 | 1E | insufficient air flow at the heat sink (soiled) |
| | | | | Electronic motor protective relay has tripped (see motor protection function of the inverter). |
| E.OHI | Error! overheat internal | 6 | 6 | Error: Overheating in the interior: If the interior temperature has dropped by at least 3 °C, E.nOHI is displayed. Then the error can be reset. |
| E. OL | Error! overload (Ixt) | 16 | 10 | An overload exceeded the permissible time (dependent on short time current limit and overload characteristic). Overload error can only be reset if OL-counter reaches 0% again and E.nOL is displayed. |
| | | | | motor wrongly wired |
| | | | | motor wrongly wired |
| | | | | inverter not correctly dimensioned |
| | | | | encoder damaged |
| poor control adjustment (overshooting) | | | | |
| | | | | Mechanical error (moved too hard, blockade) or overload in the application |
| | | | | further on next side |

Error and Status Display

| Display | COMBIVIS display | dec | hex | Meaning |
|---------|---------------------------------|-----|-----|--|
| E.OL2 | Error! overload 2 | 19 | 13 | The standstill constant current has been exceeded (see technical data and overload characteristics). The error can only be reset if the cooling time has elapsed and the message E.nOL2 is displayed. inverter not correctly dimensioned Mechanical error (moved too hard or blockade) or overload in the application |
| E. OP | Error! Overvoltage | 1 | 1 | The DC-link circuit voltage exceeds the permissible value. Braking resistor required Interference voltages at the input (use mains filter). the input voltage being too high The adjusted deceleration ramp is too short braking resistor defective or too small Deceleration jerk too short Worse alignment of the speed controller (overshoot of the actual speed after the acceleration phase) |
| E.OS | Error! over speed | 58 | 3A | Real speed is bigger than the max. output speed. |
| E.Puch | Error! power unit changed | 50 | 32 | Power circuit identification was changed. With a valid power circuit this error can be reset by writing to SY.03. If the value displayed in SY.3 is written, only the power-circuit dependent parameters are reinitialized. If any other value is written, then the default set is loaded. |
| E.Puci | Error! Unknown power unit | 49 | 31 | Error: During the initialization the power circuit could not be recognized or was identified as invalid. |
| E.PUCO | Error! Power unit communication | 22 | 16 | Error: Parameter value could not be written to the power circuit. No positive acknowledgement of the power unit. |
| E.SbuS | Error! bus synchron | 23 | 17 | Synchronization over sercos-bus not possible. Programmed response „Error, restart after reset“. |
| E.SET | Error! set | 39 | 27 | It has been attempted to select a locked parameter set. Programmed response „Error, restart after reset“. |
| | | | | further on next side |

| Display | COMBIVIS display | dec | hex | Meaning |
|---------|-------------------------------|-----|-----|--|
| E. UP | Error! underpotential | 2 | 2 | Occurs, if the DC-link voltage falls below the permissible value. |
| | | | | Voltage losses through wrong cabling. |
| | | | | inverter rating too small |
| | | | | A digital input was programmed as external error input with error message E.UP has released. |
| | | | | Mains contactor or input fuse defective |
| | | | | Input voltage is too low or instable |
| E.UPh | Error! Phase failure | 3 | 3 | One phase of the input voltage is missing (ripple-detection) |
| | | | | |
| PUIn | Error! Power unit invalid | 14 | 0E | Software version for power circuit and control card are different. Error cannot be reset. Only at F5-G B-housing. |
| A.Acc | Warning! maximum acceleration | 106 | 6A | Acceleration exceeds the limit defined by Pn.79. The response to this warning can be defined by Pn.81. |
| A.buS | Warning! Watchdog | 93 | 5D | Adjusted monitoring time (Watchdog) of communication between operator and PC / operator and inverter has been exceeded. Check wiring and bus master (PC or SPS). The response to this warning can be programmed. |
| A.dOH | Warning! drive overheat | 96 | 60 | The motor temperature has exceeded an adjustable warning level. The switch off time is started. The response to this warning can be programmed. This warning can be generated only with a special power circuit. |
| A.EF | Warning! external fault | 90 | 5A | An external signal has released an error at a programmable input. The response to this warning can be programmed. |
| A.ndOH | All-clear! drive overheat | 91 | 5B | The motor temperature is again below the adjusted warning level. The switch off time is stopped. |
| A.nOH | All-clear! overheat pow.mod. | 88 | 58 | The heat sink temperature is again below the adjusted warning level. |
| A.nOHI | All-clear! overheat internal | 92 | 5C | The temperature in the interior of the inverter is again below the warning threshold. |
| A.nOL | All-clear! overload (Ixt) | 98 | 62 | The load counter decreases again under the adjusted warning level. The warning "overload" is reset. |
| A.OH | Warning! overheat pow.mod. | 89 | 59 | A level can be defined, when it is exceeded this warning is output. The response to this warning can be programmed. |
| A.OH2 | Warning! motor protection | 97 | 61 | Warning: electronic motor protective relay has tripped. The response to this warning can be programmed. |

further on next side


Error and Status Display

| Display | COMBIVIS display | dec | hex | Meaning |
|---------|----------------------------|-----|-----|---|
| A.OHI | Warning! overheat internal | 87 | 57 | The temperature in the interior of the inverter lies above the permissible level. The switch off time was started. The programmed response to this warning message is executed. |
| A.OL | Warning! overload | 99 | 63 | A level between 0 and 100 % of the load counter can be adjusted, when it is exceeded this warning is output. The response to this warning can be programmed. |
| A.SbuS | Warning! synchron | 103 | 67 | Synchronization over sercos-bus not possible. The response to this warning can be programmed. |
| A.SET | Warning! set | 102 | 66 | It has been attempted to select a locked parameter set. The response to this warning can be programmed. |

Annex A

A.1 Overload characteristic

Release time [s]



On exceeding a load of 105% the overload integrator starts. When falling below the integrator counts backwards. If the integrator achieves the overload characteristic, the error E.OL is triggered.

A.2 Calculation of the motor voltage

The motor voltage for dimensioning of the drive is depending on the used components. The mains voltage reduces according to the following table:

| | | |
|-------------------------|----|---|
| Mains choke Uk | 4% | Example: |
| Inverter open loop | 4% | Closed loop inverter with mains- and motor choke at |
| Inverter closed loop | 8% | non-rigid supply system: |
| Motor choke Uk | 1% | 400 V mains voltage - 15% = 340 V motor voltage |
| Non-rigid supply system | 2% | |

A.3 Maintenance

All work may only be done by qualified personnel. The security must be ensured as follows:

- Disconnect power supply at MCCB
- Secure against restarting
- Await discharge time of capacitors (if necessary controlling by measurement at „+PA“ and „-“, respectively „++“ and „--“)
- Ensure loss of voltage by measurement

In order to avoid premature ageing and avoidable malfunctions, the measures mentioned

below must be carried out in the appropriate cycle.

| Cycle | Function |
|----------|---|
| Constant | Pay attention to unusual noises of the motor (e.g. vibrations) as well as of the frequency inverter (e.g. fan). |
| | Pay attention to unusual smells of the motor or frequency inverter (e.g. evaporation of capacitor electrolyte, braise of the motor winding) |
| Monthly | Check unit for loose screws and plugs and if necessary tighten up. |
| | Clean frequency inverter from dirt and dust deposits. Pay attention especially to cooling fins and protective grid of the fans. |
| | Examine and clean extracted air filter and cooling air filter of the control cabinet. |
| | Examine function of the fans of the KEB COMBIVERT. The fans must be replaced in case of audible vibrations or squeak. |

A.4 Storage

The DC link of the KEB COMBIVERT is equipped with electrolytic capacitors. If electrolytic capacitors are stored de-energized, the oxide film working as dielectric fluid reacts with the acidic electrolyte and destroy themselves slowly. This affects the dielectric strength and the capacity.

If the capacitor starts running with rated voltage, it is tried to build the oxide film abrupt again. This causes heat and gas and leads to the destruction of the capacitor.

In order to avoid defectives, the KEB COMBIVERT must be started up depending on the storage period in accordance with the following specification:

| | | |
|----------------------------|---|----------------|
| Storage period < 1 year | | |
| • | Start-up without special measures | |
| Storage period 1...2 years | | |
| • | Operate frequency inverter one hour without modulation | |
| Storage period 2...3 years | | |
| • | Remove all cables from the power circuit; especially of braking resistor or module | |
| • | Open control release | |
| • | Connect variable transformer to inverter input | |
| • | Increase variable transformer slowly to indicated input voltage (>1 min) and remain at least on the specified time. | |
| | Voltage class | Input voltage |
| | 230 V | 0...160 V |
| | | 160...220 V |
| | | 220...260 V |
| | | Residence time |
| | | 15 min |
| | | 15 min |
| | | 1 h |
| further on next side | | |

| | | | |
|--|-------|-------------|--------|
| | | 0...280 V | 15 min |
| | 400 V | 280...400 V | 15 min |
| | | 400...540 V | 1 h |
| Storage period > 3 years | | | |
| <ul style="list-style-type: none"> Input voltages as before, however double the times per year. Eventually change capacitors. | | | |

After expiration of this start-up the KEB COMBIVERT can be operated on nominal rating conditions or delivered to a new storage.


A.5 Activation of the temperature input (only housing B)

The parameter Pn.12 determines the response of the drive when terminals T1, T2 of terminal strip X1B (only housing B) are open. **The function is switched off at factory setting (value "7"), so the terminals must not be bridged.** The following responses can be adjusted:

| pn.12 | Display | Response | Restart |
|-------|---------|--|-----------------------------------|
| 0 | E.dOH | Immediate disabling of modulation | Remove fault; reset |
| 1* | A.dOH | Quick stopping / disabling of modulation after reaching speed 0 | |
| 2* | A.dOH | Quick stop / holding torque at speed 0 | |
| 3 | A.dOH | Immediate disabling of modulation | Autoreset, if no fault is present |
| 4* | A.dOH | Quick stopping / disabling of modulation after reaching speed 0 | |
| 5* | A.dOH | Quick stop / holding torque at speed 0 | inapplicable |
| 6* | none | No effect to the drive. An output can be set with CP.32/33 value „11“. | |
| 7 | none | No effect to the drive. Malfunction is not present! | |

*) If the motor is still too hot after 10 seconds, the error E.dOH is triggered and the modulation is switched off ! If overheat no longer exists, the message E.ndOH (or A.ndOH) is output. Only then the error can be reset or the automatic restart can be carried out.

It is necessary to change into the application mode to activate the temperature input. There the parameter Pn.12 can be set according to the table above. The following example shows how to change the parameter Pn.12 to value "7".



Example to set Pn.12 in application mode

Annex B

B.1 CE-Marking

CE marked frequency inverters and servo drives were developed and manufactured to comply with the regulations of the Low-Voltage Directive 2006/95/EC.

The inverter or servo drive must not be started until it is determined that the installation complies with the directive 2006/42/EC (machine safety directive) as well as the EMC-directive (2004/108/EC)(note EN 60204).

The frequency inverters and servo drives meet the requirements of the Low-Voltage Directive 2006/95/EC. The harmonized standards of the series EN 61800-5-1 in connection with EN 60439-1 and EN 60146 were used.

This is a product of limited availability in accordance with EN 61800-3. This product may cause radio interference in residential areas. In this case the operator may need to take corresponding measures.

B.2 UL marking

To be conform according to UL for the use on the North American Market the following instructions must be observed (original text in accordance with UL) :

- 240V units
Suitable For Use On A Circuit Capable Of Delivering Not More Than 10000 rms Symmetrical Amperes, 240 Volts Maximum when Protected by Fuses or see Instruction Manual for Alternate BCP.
- 480V units
Suitable For Use On A Circuit Capable Of Delivering Not More Than 10000 rms Symmetrical Amperes, 480 Volts Maximum when Protected by Fuses or see Instruction Manual for Alternate BCP.
- Maximum Surrounding Air Temperature 45°C (113°F)
- For control cabinet mounting as „Open Type“
- Use In A Pollution Degree 2 Environment
- Use 60/75°C Copper Conductors Only
- Motor protection by adjustment of current parameters.For adjustement see application manual parameters Pn.14 and Pn.15.
- Not incorporated Overspeed Protection
- Overload protection at 130 % of inverter output rated current (see type plate).
- Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the Manufacturer Instructions, National Electrical Code and any additional local codes, or the equivalent.

B.3 Additional Manuals

You find supplementary manuals and instructions for the download under

www.keb.de > Service&Downloads > Downloads

General instructions

- Part 1 EMC-and safety instructions

Service notes

- Up- /Download of parameter lists with KEB COMBIVERT
- Error messages

Instruction and information for construction and development

- Application Manual
- CAN manual
- Electronic accessories->braking resistors
- Preparation of a user-defined parameter menu
- Programming of the digital inputs
- Input fuses in accordance with UL

All documents are also available in printed version, however we have to charge a nominal fee for these.



Karl E. Brinkmann GmbH

Försterweg 36-38 • D-32683 Barntrop
fon: +49 5263 401-0 • fax: +49 5263 401-116
net: www.keb.de • mail: info@keb.de

KEB worldwide...

KEB Antriebstechnik Austria GmbH

Ritzstraße 8 • A-4614 Marchtrenk
fon: +43 7243 53586-0 • fax: +43 7243 53586-21
net: www.keb.at • mail: info@keb.at

KEB Antriebstechnik

Herenveld 2 • B-9500 Geraadsbergen
fon: +32 5443 7860 • fax: +32 5443 7898
mail: vb.belgien@keb.de

KEB Power Transmission Technology (Shanghai) Co.,Ltd.

No. 435 QianPu Road, Songjiang East Industrial Zone,
CHN-201611 Shanghai, P.R. China
fon: +86 21 37746688 • fax: +86 21 37746600
net: www.keb.cn • mail: info@keb.cn

KEB Antriebstechnik Austria GmbH

Organizační složka
K. Weise 1675/5 • CZ-370 04 České Budějovice
fon: +420 387 699 111 • fax: +420 387 699 119
net: www.keb.cz • mail: info.keb@seznam.cz

KEB Antriebstechnik GmbH

Wildbacher Str. 5 • D-08289 Schneeberg
fon: +49 3772 67-0 • fax: +49 3772 67-281
mail: info@keb-combdrive.de

KEB España

C/ Mitjter, Nave 8 - Pol. Ind. LA MASIA
E-08798 Sant Cugat Sesgarrigues (Barcelona)
fon: +34 93 897 0268 • fax: +34 93 899 2035
mail: vb.espana@keb.de

Société Française KEB

Z.I. de la Croix St. Nicolas • 14, rue Gustave Eiffel
F-94510 LA QUEUE EN BRIE
fon: +33 1 49620101 • fax: +33 1 45767495
net: www.keb.fr • mail: info@keb.fr

KEB (UK) Ltd.

6 Chieftain Business Park, Morris Close
Park Farm, Wellingborough GB-Northants, NN8 6 XF
fon: +44 1933 402220 • fax: +44 1933 400724
net: www.keb-uk.co.uk • mail: info@keb-uk.co.uk

KEB Italia S.r.l.

Via Newton, 2 • I-20019 Settimo Milanese (Milano)
fon: +39 02 33535311 • fax: +39 02 33500790
net: www.keb.it • mail: kebtalia@keb.it

KEB Japan Ltd.

15-16, 2-Chome, Takanawa Minato-ku
J-Tokyo 108-0074
fon: +81 33 445-8515 • fax: +81 33 445-8215
mail: info@keb.jp

KEB Korea Seoul

Room 1709, 415 Missy 2000
725 Su Seo Dong, Gang Nam Gu
ROK-135-757 Seoul/South Korea
fon: +82 2 6253 6771 • fax: +82 2 6253 6770
mail: vb.korea@keb.de

KEB RUS Ltd.

Lesnaya Str. House 30, Dzerzhinsky (MO)
RUS-140091 Moscow region
fon: +7 495 632 0217 • fax: +7 495 632 0217
net: www.keb.ru • mail: info@keb.ru

KEB Sverige

Box 265 (Bergavägen 19)
S-43093 Halsö
fon: +46 31 961520 • fax: +46 31 961124
mail: vb.schweden@keb.de

KEB America, Inc.

5100 Valley Industrial Blvd. South
USA-Shakopee, MN 55379
fon: +1 952 224-1400 • fax: +1 952 224-1499
net: www.kebamerica.com • mail: info@kebamerica.com

More and newest addresses at <http://www.keb.de>

| © KEB | |
|---------|--------------|
| Mat.No. | 00B60EM-KB00 |
| Rev. | 1G |
| Date | 07/2009 |