


COMBIVERT



GB INSTRUCTION MANUAL

Channel 1

Channel 2

Encoder interface

Incremental Encoder

TTL input

variable

Mat.No.	Rev.
DKF5ZEM-K001	1B



1. Safety Instructions	4
1.1 Validity	4
1.2 Qualification.....	4
2. Product Description.....	5
2.1 General.....	5
2.2 Material number	5
2.3 Scope of delivery (option or replacement delivery)	5
2.4 Mechanical installation	6
3. Description of the Interface	6
3.1 Voltage supply.....	6
3.2 Channel 1	7
3.2.1 Specifications	7
3.2.2 Description of X3A.....	7
3.2.3 Input signals channel 1.....	7
3.2.3.1 Signal tracks.....	7
3.2.3.2 Evaluation of the Zero Signal	8
3.2.3.3 Encoder breakage recognition	8
3.2.4 Connection of the encoder	9
3.2.4.1 Encoder cabel at SUB-D15	9
3.2.4.2 Encoder cable at terminal strip X3A.....	10
3.2.5 Encoder cable	10
3.2.6 Encoder line length.....	10
3.2.7 Tested encoders.....	11
3.3 Channel 2	11
4. Start-up	11
5. Error Messages.....	11

1. Safety Instructions

Prior to performing any work on the unit the user must familiarize himself with the unit. This includes especially the knowledge and observance of the safety and warning directions. The pictographs used in this instruction manual have following meaning:

	Danger	Refers to danger of life by electric current.
	Warning	Refers to possible danger of injury or life.
	Note	Refers to tips and additional information.

1.1 Validity

The information contained in the technical documentation, as well as any user-specific advice in spoken and written and through tests, are made to best of our knowledge and information about the application. However, they are considered for information only without responsibility. This also applies to any violation of industrial property rights of a third-party.

Inspection of our units in view of their suitability for the intended use must be done generally by the user. Inspections are particularly necessary, if changes are executed, which serve for the further development or adaption of our products to the applications (hardware, software or download lists). Inspections must be repeated completely, even if only parts of hardware, software or download lists are modified.

	Controlling by the user	Application and use of our units in the target products is outside of our control and therefore lies exclusively in the area of responsibility of the user.
	Use under special conditions	The used semiconductors and components of KEB are developed and dimensioned for the use in industrial products. If the KEB COMBIVERT is used in machines, which work under exceptional conditions or if essential functions, life-supporting measures or an extraordinary safety step must be fulfilled, the necessary reliability and security must be ensured by the machine builder.

1.2 Qualification

All operations serving transport, installation and commissioning as well as maintenance are to be carried out by skilled technical personnel (observe IEC 364 or CENELEC HD 384 or DIN VDE 0100 and national accident prevention rules!). According to this manual qualified staff means those who are able to recognise and judge the possible dangers based on their technical training and experience and those with knowledge of the relevant standards and who are familiar with the field of power transmission (VDE 0100, VDE 0160 (EN50178), VDE 0113 (EN 60204) as well as the appropriate regulations for your area.

	Danger by high voltage	KEB electronics components contain dangerous voltages which can cause death or serious injury. In operation, drive converters, depending on their degree of protection, may have live, uninsulated, and possibly also moving and hot surfaces. In case of inadmissible removal of the required covers, of improper use, wrong installation or maloperation, there is the danger of serious personal injury and damage to property.
---	------------------------	--

2. Product Description

Figure 1: Incremental Encoder Input TTL at Channel 1

X3B Channel 2 see material number	X3A Channel 1 Incremental encoder input TTL
--	--

2.1 General

Each of the interface cards delivered by KEB include two interfaces. As there are numerous different combinations available each interface will be described by means of separate instructions. The instruction covers the installation of the interface card, the connection as well as the start-up of a suitable encoder. Further information and the parameter adjustments are described in the application manual for the inverter/servo.

2.2 Material number

xM	F5	K8x	X	X	X	X
----	----	-----	---	---	---	---

Interface X3B	Term of delivery	0	installed	Z	Option, spare part	
	3	±10V	3008	A	Initiator	3007
	4	SSI	1015	GB	TTL-output	1019
	7	Tacho	3009	G	TTL-input	1018
	8	HTL Output	8008	B	TTL-input terminal	5002
F5	Series					
applicable for housing size	1M	D, E (circuit board 1M.F5.280-xxxx see above)				
	2M	G...U (circuit board 2M.F5.280-xxxx see above)				

- 2.3 Scope of delivery (option or replacement delivery)
- Encoder Interface
 - two instruction manuals
 - fixing bolt
 - packing material

- 2.4
- Mechanical installation
- All kind of works on the inverter may be carried out by authorized personnel in accordance with the EMC and safety rules only.
- Switch inverter de-energized and await capacitor discharge time
 - Pull off operator
 - Remove plastic cover
 - Remove fixing bolt
 - Fix interface board beginning from the socket connector straightly
 - Screw in fixing bolt
 - Adjust desired supply voltage with DIL switch
 - Attach plastic cover

3. Description of the Interface

3.1 Voltage supply



Figure 3.1 Voltage supply of control and encoder interfaces		
U _{int}	24 VDC	Internal voltage supply of the COMBIVERT (I _{max} 120 mA).
U _{ext}	Control terminal strip (X2A) of the COMBIVERT with external voltage supply 24...30 Vdc.	
24 V	Voltage output of encoder interfaces X3A und X3B for encoder supply (max. 1 A at external supply). Current I _{int} reduces itself by draw current to the 5 V output in accordance with the following formula: $I_{24V} = I_{int} - \frac{5V \times I_{5V}}{U_{int}}$	
5 V	Voltage output for encoder supply (I _{max} 300 mA). 5 V are obtained from the 24 V voltage.	

3.2 Channel 1

3.2.1 Specifications

X3A	Terminal strip 8-pole or socket SUB-D15
Interface type	Incremental Encoder Input
Input signals	5V TTL according to RS485
Inputs / tracks	A, B and N with the respective inverted signals
Limiting frequency	300 kHz
Increments per revolution	1...16383 inc (recommendation 2500 inc for speed upto 4500 rpm)
Input resistance	150 Ω
Max. line length	50 m, the value is additionally limited by the signal frequency, cable capacity and supply voltage.


3.2.2 Description of X3A

Figure 3.3.2 X3A as socket or terminal strip			
			
Figure 1		Figure 2	
PIN		Name	Description
Figure 1	Figure 2		
8	1	A+	Incremental encoder input track A
9	3	B+	Incremental encoder input track B
15	5	N+	Input zero track
12	7	5V	Voltage output 5V
11	–	24V	Voltage output 20...30V
3	2	A-	Differential signal to A+
4	4	B-	Differential signal to B+
14	6	N-	Differential signal to N+
13	8	COM	Reference potential for voltage supply
–	–	GND	Connection for shield at connector housing - is directly connected with the inverter earth. Connect-up external shield at the respective connector housing.


3.2.3 Input signals channel 1

3.2.3.1 Signal tracks

At this TTL input encoder interface the signals A+ and B+ are electrically phase-shifted by 90° rectangular signals with the respective inverted tracks A- and B-.



- 3.2.3.2 Evaluation of the Zero Signal
- The zero impulse is required to determine valid position points. In case of pure speed controls the signal does not need to be connected. In the following signal sequence the maximum permissible length of the zero impulse of the encoder is visible. The zero signal will be acquired if A+ ,B+ and N+ are at high level. By that there is only one valid position point which is independent from the travel direction.




- 3.2.3.3 Encoder breakage recognition
- For a monitoring of the encoder and the encoder cable to channel 1 the signal tracks and the zero track are monitored. If the connected encoder has no zero track, then the 5V-supply must be assigned to track N+ and COM to N- at the encoder plug. The monitoring is switched on/off with parameter Ec.42 (Ec.20 up to V2.8). The recognition of encoder breakage triggers an „error“! Encoder 1“ (value 32), if the voltage between two signal pairs is smaller than 625 mV .


3.2.4 Connection of the encoder

3.2.4.1 Encoder cabel at SUB-D15

- Encoder cable double-shielded and twisted in pairs
- Connect exterior shielding at both ends to PE/GND
- Connect interior shieldings at one side to COM
- Do not connect exterior and interior shielding



3.2.4.2 Encoder cable at terminal strip X3A



3.2.5 Encoder cable

KEB encoder cables are corresponding to the following specification:

Signal lines	3 x (2 x 0,14 mm²)
Supply lines	2 x 0,5mm²
Particularities	trailing capable, oil-resistant
Temperature range	constant up to 80 °C
Color	green RAL 6018

3.2.6 Encoder line length

The maximum line length of the encoder cable is 50 m. It is limited by the signal frequency, cable capacity and the line resistance.

Encoder cable length =	$\frac{U - U_{min}}{I_{max} \cdot 2 \cdot R}$
max. encoder current I _{max} :	see encoder description
Supply voltage U:	5,2V
min. supply voltage U _{min} :	see encoder description
KEB encoder cable resistance R:	0,036 Ω/m at 0,5 mm²

3.2.7 Tested encoders

The following TTL incremental encoders have been tested by KEB on it application:

- Heidenhain ROD 426

However, this does not restrict the use of rotary encoder with same specifications of other manufacturers.

3.3 Channel 2

The description of input X3A is depending on the used encoder interface. It is described in a separate manual.

4. Start-up

After the installation or exchange of an encoder interface some adjustments of the inverter/servo software have to be done before operation:

- Switch on inverter
- Select application mode
- Select parameter Ec.0 and check whether value „1: Incremental In“ is displayed. The displayed value has to be confirmed by „ENTER“ in any case.
- Select Ec.1 and adjust increments per revolution.
- Select Ec.42 (Ec.20 upto V2.8) and adjust the encoder breakage recognition dependent on the case of operation.
- If several slaves are connected, deactivate the terminating resistor with Ec.20 Bit 1 (do not switch off at last slave).

5. Error Messages

Error messages and their meaning are described in Chapter 9 of the application manual.



Karl E. Brinkmann GmbH

Försterweg 36-38 • D-32683 Barntrup
fon: +49 5263 401-0 • fax: +49 5263 401-116
net: www.keb.de • mail: info@keb.de

KEB worldwide...

KEB Antriebstechnik Austria GmbH

Ritzstraße 8 • A-4614 Marchtrenk
fon: +43 7243 53586-0 • fax: +43 7243 53586-21
net: www.keb.at • mail: info@keb.at

KEB Antriebstechnik

Herenveld 2 • B-9500 Geraardsbergen
fon: +32 5443 7860 • fax: +32 5443 7898
mail: vb.belgien@keb.de

KEB Power Transmission Technology (Shanghai) Co.,Ltd.

No. 435 QianPu Road, Songjiang East Industrial Zone,
CHN-201611 Shanghai, P.R. China
fon: +86 21 37746688 • fax: +86 21 37746600
net: www.keb.cn • mail: info@keb.cn

KEB Antriebstechnik Austria GmbH

Organizační složka
K. Weise 1675/5 • CZ-370 04 České Budějovice
fon: +420 387 699 111 • fax: +420 387 699 119
net: www.keb.cz • mail: info.keb@seznam.cz

KEB Antriebstechnik GmbH

Wildbacher Str. 5 • D-08289 Schneeberg
fon: +49 3772 67-0 • fax: +49 3772 67-281
mail: info@keb-drive.de

KEB España

C/ Mitjer, Nave 8 - Pol. Ind. LA MASIA
E-08798 Sant Cugat Sesgarriques (Barcelona)
fon: +34 93 897 0268 • fax: +34 93 899 2035
mail: vb.espana@keb.de

Société Française KEB

Z.I. de la Croix St. Nicolas • 14, rue Gustave Eiffel
F-94510 LA QUEUE EN BRIE
fon: +33 1 49620101 • fax: +33 1 45767495
net: www.keb.fr • mail: info@keb.fr

KEB (UK) Ltd.

6 Chieftain Buisiness Park, Morris Close
Park Farm, Wellingborough GB-Northants, NN8 6 XF
fon: +44 1933 402220 • fax: +44 1933 400724
net: www.keb-uk.co.uk • mail: info@keb-uk.co.uk

KEB Italia S.r.l.

Via Newton, 2 • I-20019 Settimo Milanese (Milano)
fon: +39 02 33535311 • fax: +39 02 33500790
net: www.keb.it • mail: kebitalia@keb.it

KEB Japan Ltd.

15-16, 2-Chome, Takanawa Minato-ku
J-Tokyo 108-0074
fon: +81 33 445-8515 • fax: +81 33 445-8215
mail: info@keb.jp

KEB Korea Seoul

Room 1709, 415 Missy 2000
725 Su Seo Dong, Gang Nam Gu
ROK-135-757 Seoul/South Korea
fon: +82 2 6253 6771 • fax: +82 2 6253 6770
mail: vb.korea@keb.de

KEB RUS Ltd.

Lesnaya Str. House 30, Dzerzhinsky (MO)
RUS-140091 Moscow region
fon: +7 495 550 8367 • fax: +7 495 632 0217
net: www.keb.ru • mail: info@keb.ru

KEB Sverige

Box 265 (Bergavägen 19)
S-43093 Hälsö
fon: +46 31 961520 • fax: +46 31 961124
mail: vb.schweden@keb.de

KEB America, Inc.

5100 Valley Industrial Blvd. South
USA-Shakopee, MN 55379
fon: +1 952 224-1400 • fax: +1 952 224-1499
net: www.kebamerica.com • mail: info@kebamerica.com

More and newest addresses at <http://www.keb.de>

© KEB	
Mat.No.	DKF5ZEM-K001
Rev.	1B
Date	10/2011